



## PrintersKleen™ Usage Guide

**Anilox rolls** - PrintersKleen™ may be sprayed on rolls and wiped off. It may be run in the fountain for a while and then water rinsed. The ideal way to use it is to immerse your anilox rolls in a trough or container of the PrintersKleen™ and then taken out and rinsed off with water. The amount of ink plugging the cels will determine the amount of time to immerse the roll in this solution. If a program of regular cleaning is instituted, the time to soak a roll will be significantly reduced.

**Printing plates** - PrintersKleen™ may be used in a shallow dish or container to clean old or built up inks on printing plates. It may also be used out of a spray bottle to clean plates while still on the press. PrintersKleen™ will not affect rubber or photopolymer plates.

**General purpose cleaning** - PrintersKleen™ may be used to clean various areas on the printing press and surrounding spaces. In fact many of our customers are using it to mop up ink rooms and places which get dirty with printing inks on a daily basis.

Two areas that PrintersKleen™ will benefit your firm a great deal:

**Environmental** - companies are heading toward decreased usage of solvents and other caustic materials in their plants. This will help everyone to have a cleaner environment and show that your company is environmentally friendly.

**Health & Safety** - Because PrintersKleen™ is a non-hazardous, non-toxic, non-flammable solution, the chances of employee injury are greatly reduced. As you know, the fewer dangerous substances used in a plant, the less chance of employee injury with accompanying loss of productivity.